

V16 LCD Keypad Tutorial Video V16 LCD 键盘教程影片

Change Password_更换密码

<https://youtube.com/shorts/xgdmkka-SQY>

Set Clock_设置时间

<https://youtube.com/shorts/yYkUBX8r8rg>

Set Date_设置日期

<https://youtube.com/shorts/se2k9okHQLU>

Set Frist Phone Number_设置第一个电话号码

<https://youtube.com/shorts/-zDUZKErN8>

Set Second Phone Number_设置第二个电话号码

<https://youtube.com/shorts/S-uv5-nvBC8>

ByPass Zone_有问题的区暂时关闭

<https://youtube.com/shorts/e82X-zcvjtU>

View Trouble_查看故障

<https://youtube.com/shorts/cRhINlxDo3k>

View Event Log_查看事件日志

https://youtube.com/shorts/rG_0AtXO5wk

Set Schedule arm_设置时间表ARM

https://youtube.com/shorts/_oHXlijVxDA

Set Schedule Disarm_设置时间表Disarm

<https://youtube.com/shorts/K8lq580z4aU>

Set Schedule arm_设置时间表ARM

<https://youtube.com/shorts/WtML4XKUQ9g>

Set Schedule Disarm_设置时间表Disarm

<https://youtube.com/shorts/8HVHxV8gtaQ>

Bluguard P2P Module How to Connet_怎样连接Bluguard P2P Module

<https://youtu.be/WFwtCg1bOrE>